



# Caire Liberator





	Description	Pioneer #	Man. Part #
7	Economizer Assembly	P627	13277851S
8	Vent Valve	P628	20580870
16	0-15 LPM Vaporizer Coil	P669	11018994S
17	0-15 LPM Breathing Coil	P668	11940524S
28	Drain Tube Assy	P618	10657807
36	Manifold O-Ring	P629	CA405086
38	Split-Lock Washer - Manifold	P633	CA200038
39	Flow Control Valve Extension G4	P624	13168347
39	Flow Control Valve Extension w/O-ring	P624N	13168347
52	Manifold Bolts - SS 1/4-20*5/8"	P642	2910501
62	Cable Tie	P699	10735983
72	Male Quick Connect	P631	15101621
75	Pop-Off Assembly	P648	11908049
77	Pop-Off Sleeve	P654	10576441
86	Humidifier Adaptor Elbow	P650	CA405451
87	Condensate Bottle Bracket	P799	10584513
88	Condensate Bottle	P347	CA404899

# Liberator Plumbing Assy.



	Description	Pioneer #	Man. Part #
1	Shroud - G4 Blue	P609	13726943
2	Liberator Label	P655	13712200
3	Shroud Bottom Label	P603	13657677
4	Shroud Washer	P797	2910991
5	Shroud Screw	P796	2910391


# Liberator Shroud



# Meter Assy.

	Description	Pioneer #	Man. Part #
1	Meter Screw	P677	CA405164
2	G4 Meter	P634	13352401
3	Bracket G4	P617	13708104
4	Ground Screw	P677	CA405164

	Description	Pioneer #	Man. Part #
1	Flow Control Knob - Red	P880	10567941
2	Flow Control Valve Screws	P824	CA405164
3	16 Position Locking Plate	P823	13095627
4	0-15 LPM 16 Position Number Disc	P822	13086149
5	0-15 LPM 16 Position Flow Control Valve	P821	13110145
6	30 PSI Relief Valve	P615	13110217
7	Humidifier Adapter Extension w/Oring	P624N	10567941
8	Humidifier Adapter Elbow	P650	CA405451



# FCV Assy.